

Door/Window Magnet Installation Guide

Materials

- Double sided sticky tape
- Guardian Protection provided magnet

Directions

- Remove the magnet from the packaging.
- **2.** Ensure that the surface is clean and dry before applying the magnet.
- **3.** Turn on the chime feature at the keypad to ensure the magnet is in the right place before applying the double sided tape. The chime should sound if the magnet is too far away from the transmitter.
 - There will be a groove, line or arrow on the magnet.
 - Match up the line or arrow with the line or arrow on the currently mounted door/window transmitter.
 - Please note, the distance between the transmitter and magnet must not be more than ³/₄ of an inch when the door/window is closed.
- **4.** Apply double sided sticky tape to the underside of the magnet.
- **5.** Mount on the door or window.
- **6.** See example below

